

SAFETYCELL CELLPHONE COMPATIBILITY CHART

UPDATED 10-24-06

PHONE MODELS

ADAPTER NEEDED

AT&T	3625	3700	3770	6650	NONE NEEDED
AT&T	3815				ESI-NK600
AUDIOVOX	CDM-3000	MVX-430	MVX-475	MVX-565	
	CDM-3000XL	MVX-440	MVX-480	PCX-3600XL	NONE NEEDED
	CDM-4000	MVX-450	MVX-480XL	TDM-2500	
	CDM-4000XL	MVX-460	MVX-530	TDM-2500XL	
	CDM-4500	MVX-465	MVX-535		if you have an audiovox you do not need an adapter
	MVX-425	MVX-470	MVX-560		
ERICKSON	A2218	D750	J300A	K300	
	K500	K700I	K750	P800	ESI-ER800
	P900	P910	R300	S700I	
	S710A	T20	T28	T29	
	T60	T61-SERIES	T62U	T68I	
	T200	T206	T226	T237	
	T290A	T300	T306	T310	
	T316	T600	T608	T610	
	T616	T630	T637	W5501	
	Z200	Z300	Z500	Z530	
	Z600				
FUJITSU	3625	F80P-173	ST	XL	NONE NEEDED
GE	CT500	CT630	CT750	DT3325	
	CT550	CT650	CT800	DT3500	ESI-ER300
	CT620	CT700	DT3000	DT5525	
GE	CT-640	CT-650			ESI-ER700
HANDSPRING	180	180G	270	270G	
	300				ESI-NK8000
LG	LG	LGIC	LGC-320	LGC-330W	ESI-LG100
	LGC-2300W	LGP-2320			
MITSUBISHI	AH129	AH270	CT750	DT3325	
	AH131	AH350	CT800	DT3500	NO ADAPTER NEEDED
	AH250	AH365	DT3000	DT5525	
MOTOROLA	NEXTEL I500	NEXTEL I700	NEXTEL I1000	NECXTEL I2000	ESI-i
MOTOROLA	SATELITE 9500				NONE AVAILABLE
MOTOROLA	SATELITE 9505				NO ADAPTER NEEDED
MOTOROLA	ALMOST ALL MOTOROLA PHONES DO NOT USE ADAPTERS. THE EXCEPTIONS ARE;				
	V3	V3c	V3i	V3X	RAZR ADAPTER
	V3M	RAZR	U6	PEBL	
	L7	SLVR	L6	L2	
	V323	V325	V360	V361	
	V365	KRZR	or any Motorola that has the mini USB connector		

NOKIA	2110	2120	2160	2160i	ESI-NK210
	2160EFR	2160P2	2168	2180	
	2190	TD815			
NOKIA	3285	5120	5125	5160	ESI-NK610
	5165	5170	5180	5185	
	5190	6110	6120	6160	
	6160i	6161	6162	6168	
	6170	6180	6185	6190	
	7190	6385	6390	7160	
If your phone has a 7 bar connector on the bottom, use this adapter					
<u>GENERAL COMMENTS REGARDING NOKIA PHONES AND ADAPTERS</u>					
All Nokias need adapters. With the exception of a couple of old phones, they all use one of 3 styles offered. You need only look at where you plug in an ear piece to determine which adapter you need.					
If your phone has a 2.5mm round ear piece jack, use the NK-8000 adapter					
If your phone has a 7 bar connector on the bottom, use the NK-610 adapter					
if your phone has a 14 bar connector on the bottom, use the NK-14 pin adapter					
Below is a listing of Nokia phones and their corresponding adapters. If your phone is not on the list, refer to the general guidelines above to determine which one you need.					
NOKIA	101	1000	121	128	NO ADAPTER AVAILABLE
NOKIA	5120	6120	6190		ESI-NK600
	5125	6160	7160		
	5160	6160i	7190		
	5165	6161			
	5170	6162			
	5180	6168			
	5185	6170			
	5190	6180	<u>your phone has a 7 bar connector on the bottom</u>		
	6110	6185			
NOKIA	1100	3395	3650	8390	ESI-NK8000
	1221	3520	6590	8890	
	1260	3560	6590i	8890-G	
	1261	3590	8260		
	3360	3595	8265		
	3361	3600	8270		
	3390	3620	8290		
NOKIA	3285	5170	6160		NK-14 PIN
	5100	5180	6160i		
	5120	5185	6161		
	5125	5190	6162		
	5160	6110	6168		
	6360	6185	6180		
	6385	6190	6170		
	5165	6120			YOUR PHONE HAS 14 BARS ON THE BOTTOM
OKI	1145	1375	1435		NO ADAPTER NEEDED
	1150	1410	1475		
	1325	1415	CD-3500		
	1335	1430			
PANASONIC	EB-H10	EB-H55	EB-H105		NO ADAPTER NEEDED
	EB-H20	EB-H66	EB-H205		
	EB-H40	EB-H70			
PANASONIC	EB-H63	EB-H64			NON COMPATIBLE
PRESTIGE	PR-140	PR-150			NO ADAPTER NEEDED

<u>QUALCOMM/</u>	QCP-860	QCP-1960	QCO-2760		ESI-Q6
Please note: Qualcomm and Kyocera are the same company and interchange part numbers					
<u>KYOCERA</u>	PDQ800	Q800	QCP800	QCP3035	
	PDQ1900	Q1900	QCP1900	QCP2027	NO ADAPTER NEEDED
	QCP2035	QCP2035A	7135 tales NK8000 adapter		
<u>SAMSUNG</u>	SCH-400	SCH-2510	SCH-8500		
	SCH-411	SCH-3500	SCH-N100		NO ADAPTER NEEDED
	SCH-850	SCH-3510	SCH-T100		
	SCH-2000	SCH-4010	ALL OTHER SAMSUNGS		
	SCH-2010	SCH-6100			
<u>SANYO</u>	SCP-3000				NO ADAPTER NEEDED
<u>SEIMANS</u>	S-46	M-46	A55	C55	SEIMANS ADAPTER
	M55	S55	SL55	A56	
	C56	CT56	S56	SL56	
<u>SONY</u>	CM-SB200	CM-ZS300			NO ADAPTER NEEDED
<u>SONY or QUALCOMM</u>		QCP-820	QCP-1920	QCP-2700	
	Z-100	Z-200	CM-Z100	CM-Z200	
	CM-A1100	CM-S2100	CM-S3100	CM-B1200	ESI-Q8
	CM-B2200	CM-B3300	CM-M1300	CM-B3300	
	CM-M1300	CM-M2300	CM-M3300		
<u>SPRINT</u>	TOUCHPOINT	SCH-2000	SCP-3000		NO ADAPTER NEEDED
<u>TOSHIBA</u>	TCP-1000	TCP-900	ANA--9500	MER-9500	NO ADAPTER NEEDED
	EXP-9500				